

INSTALLATION

Tools

- Drill and 1/4" bit
- 5/32 Hex Key (included)
- 7/16" Wrench
- Needle Nose Pliers

1. Use needle nose pliers to loosen footboard cover and rotate forward out of the way.



2. Using the **HEEL GUARD™** as a template, place in rear corner of metal base plate. Be careful to align the rod with the inside edge of the base plate. Mark the holes first.



3. Drill 1/4" holes.



4. Use the enclosed bolts and locking nuts to secure the **HEEL GUARD™**.



3. Reinstall the footboard cover.

